

RC Weathering Guide: Keswick Green Defender

Step 1: Base Paint

Apply Keswick Green and allow to fully cure.

Step 2: Satin Clear Coat

Apply a light satin coat to reduce gloss and prepare surface.

Step 3: Fade Mix

3 drops green, 1 drop sky, 1 small drop white. Thin heavily and apply to hood and roof.

Step 4: Chipping

Apply subtle edge wear using dark tones.

Step 5: Rust

Light rust on hinges and seams only.

Step 6: Dust

Apply pigments and light airbrush dust from bottom up.

Final Tip: Stop early. Subtle weathering looks more realistic.