

TRX4M Defender V2 Weathering Guide (Keswick Green)

Goal: Improve realism by adding depth, contrast, and story.

Step 1 – Vertical Streaking:

Apply small dots of dark brown wash under windows, hinges, and handles. Pull downward with a damp brush.

Step 2 – Panel Line Depth:

Use a thin dark wash to define door gaps, panel lines, and bolts.

Step 3 – Lower Body Dirt Layers:

Add darker dirt tones behind wheels and along the bottom. Blend upward for a natural gradient.

Step 4 – Rear Door Details:

Add subtle rust on hinges, streaks from bolts, and heavier dirt at the bottom.

Step 5 – Edge Wear:

Use a sponge or fine brush to add very light chipping on edges and corners.

Stop Rule: Do not overdo it. Focus on contrast and realism.

Document your progress: before, during, and after photos.